

## High pressure jets (4 pcs.) for cleaning of hopper.

Issue 00  
Sheet 1 of 1

For the purpose of cleaning the hopper after use, 4 high pressure jets can be installed in the hopper. The use of these jets do however require the machine to have a high pressure water system.

The jets are operated manually from outside the cab, where a valve is placed underneath the hopper.



*Jets mounted inside the hopper*



*Valve to operate the jets, placed underneath the hopper*